





### Desk Clamp Base (VESA:200x100)

**Step 1**

Option A: A1, A2

Option B: B1, B2

M:  $\leq 0.3^{\circ}$ - $2^{\circ}$  8-50mm

Min. 8.0mm

**Step 2**

K

D

R: 5mm

G: 2.5mm

### Grommet Mount Base

**Step 1**

$\leq 0.3^{\circ}$ - $2^{\circ}$  8-50mm

L, M, N

**Step 2**

K

D

G: 2.5mm

### Desk Stand

**Step 1**

K, L

**Step 2**

D

G: 2.5mm

### Desk Clamp Base (VESA:100x100)

**Step 1**

Option A: A1, A2

Option B: B1, B2

M:  $\leq 0.3^{\circ}$ - $2^{\circ}$  8-50mm

Min. 8.0mm

R: 5mm

**Step 2**

K

D

G: 2.5mm

Kensington lock hole

### Dual Type VESA:200x100 Installation Process

**Step 3**

G: 2.5mm

C, D, H

**Step 4**

J

**Step 5**

F, A, E

**Step 6**

Lock up

**Additional Installation Process (For Quad Model only)**

B, J, C, B, D, H, K, P, Q, L

### Dual Type VESA:100x100 Installation Process

**Step 3**

G: 2.5mm

C, D, H

**Step 4**

J

**Step 5**

F, A

**Step 6**

Lock up

**Additional Installation Process (For Quad Model only)**

B, J, C, B, D, H, K, P, Q, L

### Swivel & Tilt ; Rotate(Pivot) Torque Adjust

Tilt:  $\pm 15^{\circ}$

Swivel:  $\pm 20^{\circ}$

Allen wrench: 5mm

Arm Adjust(For each Arm):  $15^{\circ}$

Rotate 360°

### Swivel & Tilt ; Rotate(Pivot) Torque Adjust

Tilt:  $\pm 20^{\circ}$

Swivel:  $\pm 20^{\circ}$

Allen wrench: 2.5mm

Arm Adjust(For each Arm):  $15^{\circ}$

Rotate 360°

### Horizontal & Vertical Adjust Cable Management

### Horizontal & Vertical Adjust Cable Management

#### Weight Capacity list VESA:200x100

	Desk Clamp Base	Grommet Mount Base	Desk Stand
Dual Type			
Quad Type			

#### Weight Capacity list VESA:100x100

	Desk Clamp Base	Grommet Mount Base	Desk Stand
Dual Type			
Quad Type			