



### TABLE TOP MOBILE SCREEN INSTRUCTION LITERATURE

- Open all four leg supports by folding legs down 90° and locking into place. Place projection screen housing on stable, level surface with support legs facing down.
- Hold left side (side with carry handle) of housing in left hand and right side in right hand as shown and unlock screen by depressing two buttons (front and back) on right side housing with thumb and index finger.
- Open screen slowly by pulling two screen halves in opposite direction until fully open
- Position on flat and sturdy table-top for data projection viewing
- Repeat steps in reverse order to close. Guide screen gently to closed position. Do not let screen retract freely as damage may result to screen.
- To close leg support, squeeze leg together at base and slowly rotate towards housing. Repeat for each leg

#### Note:

Do not allow screen to be exposed to direct sunlight as it could fade White matte screen  
 Do not place opened screen closed to door or air movement area  
 Provide proper adult supervision when using the screen around children

